



PRIVACY INSTALLATION. Read Carefully!!



1. Install Split-Spindle from Outside until STOP-PIN is against latch.
2. With STOP-PIN firmly against latch attach inside adaptor and tighten set screw on Inside Adaptor first! (IMPORTANT)
3. Install Outside adaptor and tighten set screw firmly.
4. Thread on PRIVACY-BUTTON and test operation.

TEMPLATE

